

From February 1st, 2017 SAMES Technologies SAS becomes SAMES KREMLIN SAS A partir du 1/02/17, SAMES Technologies SAS devient SAMES KREMLIN SAS







# High Voltage Unit UHT 158 EEx e

FRANCE

USA

**SAS SAMES Technologies.** 13 Chemin de Malacher 38243 Meylan Cedex Tel. 33 (0)4 76 41 60 60 - Fax. 33 (0)4 76 41 60 90 - www.sames.com **Exel North America** 45001 5 Mile Road, Plymouth, Michigan, 48 170 Tel. (734) 979-0100 - Fax. (734) 927-0064 - www.sames.com

Index revision : A

1

7068

All communication or reproduction of this document, in any form whatsoever and all use or communication of its contents are forbidden without express written authorisation from SAMES Technologies.

The descriptions and characteristics mentioned in this document are subject to change without prior notice.

#### © SAMES Technologies 2009



VARNING : SAS Sames Technologies is registered with the Ministry of Labour as a training institution.

Throughout the year, our company offers training courses in the operation and maintenance of your equipment.

A catalogue is available on request. Choose from a wide range of courses to acquire the skills or knowledge that is required to match your production requirements and objectives.

Our training courses can be delivered at your site or in the training centre at our Meylan head office.

Training department: Tel. 33 (0)4 76 41 60 04 E-mail: formation-client@sames.com

SAS Sames Technologies operating manuals are written in French and translated into English, German, Spanish, Italian and Portuguese.

The French version is deemed the official text and Sames will not be liable for the translations into other languages.

Index revision : A

7068

# High Voltage Unit UHT 158 EEx e

1. Warnings	4
1.1. The high voltage unit UHT 158 marking	4
2. Introduction	4
3. Description	4
4. Characteristics	5
4.1. Electrical characteristics	
5. Safety precautions	6
6. Maintenance	6
6.1. Electrical connexions	
7. Spare parts	8
7.1. "UHT 158 EEx e" High Voltage Unit	

# 1. Warnings

WARNING : This eqipment may become a safety hazard if it is not operated, disassembled and reassembled in accordance with the instructions given in this manual. See the equipment manual.

#### 1.1. The high voltage unit UHT 158 marking



## 2. Introduction

The high voltage units UHT 158 EEx e permit to feed a paint applicator with high voltage without high voltage cable. These units are mainly used for the Nanobell atomizers.

#### 3. Description

The UHT 158 EEx e comprises :

- A moulded part with :
  - High voltage elements (transformer, cascade, measuring resistance and priming resistance),
  - Low voltage elements (recognition chip and protection elements)
  - High voltage outlet adapted.

# 4. Characteristics

### 4.1. Electrical characteristics

Max input voltage	$\leq$ 60 V RMS – 25 kHz roughly	
Outlet voltage	70 kV, negative polarity.	
Outlet current	100 µA, (*)	
Outlet power	7 W max	

#### 4.2. Mechanical characteristics

1	125,5 mm	
2	40 mm	
3	80 mm	
4	41 mm	

Weight: 0,440 Kg





# 5. Safety precautions

- Clean and grease with dielectric grease before fitting.
- Never assemble or disassemble with voltage on.
- Do not put the low voltage cable into contact with solvent.
- Cable length between high voltage unit and generator GNM 200 (unit cable + any extension) is 30 m.

# 6. Maintenance

#### 6.1. Electrical connexions

Cable diameter: = CEE 0,5 mm<sup>2</sup> or 0,34 mm<sup>2</sup> Cable diameter: US = Gauge AWG 20 or AWG 22

			Description signal		
1		Ground			
2	А	Yellow 0,34 mm <sup>2</sup>	HV Signal		
3	В	Green 0,34 mm <sup>2</sup>	HV I Signal		
4	С	White 0,5 mm <sup>2</sup>	Transformer input		
5	D	Brawn 0,5 mm <sup>2</sup>	Transformer output		
6	Е	Pink 0,34 mm <sup>2</sup>	L Signal		
7	F	Grey 0,34 mm <sup>2</sup>	H Signal		
	G	Ground			

The cable used for the connections must respect:

- wire diameter comprised between 0,3 mm<sup>2</sup> and 0,8 mm<sup>2</sup>
- diameter: 4 mm mini and 8 mm maxi.
- a complete shielding and a second shielding for each pair of wire

Nota : Should some wires are not used, they should be connected to the ground



DES01204

G

## 6.2. Cable replacement

1	Stuffing box nut
2	Stuffing box body
3	Stuffing box union

- 1 Maintaining the body, loosen the nut in order to unblock the cable
- 2 Unscrew the union in order to access to the connections
- 3 Unplug each electrical wire
- 4 Unscrew the body and keep the union5 Replace the cable
- 6 Replace the seal washer if needed



DES01555

# 7. Spare parts

# 7.1. "UHT 158 EEx e" High Voltage Unit



ltem	Part number	Description	Qty	Sale unit	Maintenance Level for Spare part (*)
1	910007566	UHT158 EEx e, 70kV with program	1	1	3
2	1408523	Seal washer	1	1	2
3	1310068	Stuffing box union	1	1	2
4	X7DDZU005	Brass washer	2	1	3
5	X7CVCB180	Brass screw M5x8	1	1	3

(\*) Level 1: Standard maintenance

Level 2: Corrective maintenance

Level 3: Exceptional maintenance

## 7.2. Cables

Note: Each cable has a defined length; for other lengths, please, contact SAMES Technologies.



WARNING : Cable length between the High Voltage Unit and the Control Modul GNM (unit cable + any extension) shoud not exceed 30m.